

- 2 6 Qty. (1) Clip Hex Bolt (5/8" - 11 x 2" Grade 8) Qty. (8) 3 7 Qty. (1) Drawbar Qty. (2) Spacer Plate 4 8 Qty. (8) Hex Nut (5/8" - 11 Grade 8) Qty. (1) Hitch
 - Measure chassis width. If chassis width is under 34.75" then remove shim plates(Item 7). To remove shim plates: remove fasteners (Item 4, 5 & 6). Discard spacer plates (Item 2). Reinstall fasteners and align side brackets. Snug up fasteners.
 - 2. Raise hitch into position. Weld hitch to chassis as shown above.
 - 3. Torque hitch fasteners (Items 4,5 & 6) to:

Tighten 5/8" - 11 Grade 8 fasteners to 190 lb.-ft. (257.6 N*M)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684.

z 2007, 2015 Cequent Performance Products – Printed in Mexico	Sheet 1 of 1	38124N	03-24-15	Rev. D
---	--------------	--------	----------	--------