

57300

DODGE TO GM/FORD OEM 7-WAY ADAPTER

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

1/5/2011

English

1. Remove the existing 7-Way from the vehicle.
2. Disconnect the vehicle's trailer harness from the 7-Way connector by separating the housings. There is a red lock that will need to be released as shown (A). Take care not to damage the housing's lock.
3. Connect the adapter harness to the vehicle's harness (B). Make sure the connectors are fully inserted with the locking tab in place.
4. Connect the adapter harness your new 7-Way connector (C) and install the new 7-Way connector in the mount location (D).
5. Test all functions for proper operation.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813



