CLASS 2 TRAILER HITCH R2-0850 CHEVROLET IMPALA


TOOLS REQUIRED: DRILLS: 1/2"

WRENCHES:13mm, 9/16", 3/4"

3,500 LB GROSS TRAILER WEIGHT, 300 LB TONGUE WEIGHT. WARNING: CONSULT VEHICLE OWNERS MANUAL FOR TOWING RECOMMENDATIONS AND LIMITATIONS. THIS PRODUCT IS DESIGNED FOR TRAILER TOWING ONLY AND SHOULD NOT BE USED FOR ANY OTHER PURPOSE.

WARNING: USE ONLY RIGID HITCH APPROVED AND MANUFACTURED DRAW BAR INSERT OR WARRANTY WILL BE VOID

NOTE: INSTALL PARTS LOOSELY UNTIL ALL ATTACHMENTS HAVE BEEN MADE TO VEHICLE



NOTE: IF DUAL EXHAUST IS PRESENT EXHAUST NEEDS TO BE LOWERED FROM HANGERS FOR INSTALLATION

- 1. REMOVE (6) 8MM BOLTS THAT ATTACH BUMPER TO FRAME
- 2. SLIDE EARS ON MAIN TUBE OF HITCH BETWEEN BUMPER AND FRAME
- 3. LOOSELY RE-INSTALL (6) 8MM BOLTS THROUGH THE FRAME, HITCH EARS, AND BUMPER
- 4. CENTER HITCH ON VEHICLE AND POSITION SO THAT REAR HANGER CONTACTS THE FLAT SURFACE OF THE BUMPER.
- 5. USING THE HITCH AS A TEMPLATE, DRILL THE FOUR HOLES IN BUMPER AND TWO HOLES IN FRAME CROSS MEMBER WITH 1/2" DRILL.
- REMOVE THE (6) 8MM BOLTS THAT ATTACH BUMPER AGAIN AND REMOVE THE HITCH.
- 7. ASSEMBLE (2) 1/2" CARRIAGE BOLTS AND 1/2" SQ. HOLE BLOCK PLATES
- 8. USING FISHWIRE PROVIDED FISH CARRIAGE BOLT AND BLOCK PLATE ASSEMBLIES THROUGH ACCESS HOLES IN FRAME CROSS MEMBER INTO 1/2" DRILLED HOLES, AND INSERT (2) 3/8" SQ. U-BOLTS INTO HOLES DRILLED IN BUMPER.
- 9. USING CARE NOT TO PUSH BOLTS BACK UP INTO BUMPER AND FRAME, SLIDE EARS OF HITCH BETWEEN BUMPER AND FRAME, AND RAISE HITCH INTO POSITION.
- 10. LOOSELY INSTALL (4) 3/8" FLAT WASHERS, LOCK WASHERS AND NUTS ON TWO 3/8" U-BOLTS IN BUMPER, AND (2) 1/2" FLAT WASHERS, LOCK WASHERS AND NUTS ON CARRIAGE BOLTS IN FRAME.
- 11. RE-INSTALL (6) 8MM BOLTS THROUGH FRAME, HITCH EARS, AND BUMPER.
- 12. TIGHTEN ALL FASTENERS TO APPROPRIATE TORQUE SPECIFICATIONS AT THIS TIME

NOTE: RE-ATTACH HANGERS IF EXHAUST WAS LOWERED DURING INSTALLATION.

TIGHTEN ALL FASTENERS TO THE TORQUE SPECIFICATIONS SHOWN BELOW

HARDWARE PACKAGE:

(2) 3/8" SQ. U-BOLTS

2) 1/2-13 X 1-3/4" CARRIAGE BOLTS 2) 1/4 X 1 X 2 SQ. HOLE PLATES

2) 1/4 X 1 X 2 3Q. HOLE 2) 1/2" FLAT WASHERS (2) 1/2" LOCK WASHERS (2) 1/2" HEX NUTS

(4) 3/8" FLAT WASHERS (4) 3/8" LOCK WASHERS (4) 3/8" HEX NUTS (1) 1/2" FISH WIRE

(1) R2-0106-S DRAWBAR KIT

GIVE THIS INSTRUCTION SHEET TO VEHICLE OWNER

BOLT TIGHTENING TORQUE (LB-FT) BOLT SIZE TORQUE BOLT SIZE TORQUE 3/8" 25 LB FT MM8 20 LB FT 38 LB FT 10MM 7/16" 50 LB FT 1/2" 12MM 68 I B FT 60 LB FT 3/4" 120 LB FT

THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR SAE AND VESC REGULATION V-5 FOR CONNECTING DEVICES AND TOWING SYSTEMS. DO NOT MODIFY THIS PRODUCT. INSTALL ONLY ON SPECIFIED VEHICLES IN GOOD CONDITION.



3301 WEST BURNSVILLE PARKWAY BURNSVILLE, MN 55337