



1. Insert Upper Handle (A) into Lower Handle (B) and bolt together.
2. Insert Handle Assembly (A&B) into Frame (C) and bolt together.
3. Bolt Cross Support (D) onto Frame/ Handle tabs.
4. Install one Cotter Pin and one wheel (E) on axle (F). Slide axle through frame (C) and install the other wheel (E) and Cotter Pin.
5. Insert Dolly Ball (G) into top of frame (C) and adjust to desire height.
6. Engage dolly ball into trailer coupler to move trailer by hand.