

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

APPLICATIONS

Make	Model
Lexus	RX 350 with tow package
Lexus	RX 450h

CUSTOM WIRING CONNECTOR



WIRING LOCATION GUIDE

SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S5 - Behind driver side rear bumper



NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

None

⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate the vehicle taillight wiring connector (A). The connector plug will be similar to the custom wiring connector plug. Remove the protective cap from the vehicle plug and set aside (B).

Step 2

Insert the custom wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place (C).

Step 3

When in use, route the 4-flat to the center of the vehicle and out of the trunk. When not in use, roll up and store in a convenient, out of the way location inside the trunk. Secure any loose wires with the provided cable ties (D).

Step 4

Some models may need to be programmed to accept the new custom wiring connector. This must be done by a dealer.

Step 5

Reinstall all items removed during install. Install the provided 4-flat dust cover to help prevent corrosion.

