
CLASS 1 TRAILER HITCH RT-856 Saturn Astra

TOOLS REQUIRED: DRILLS: NONE WRENCHES: 11/16"

2,000 LB GROSS TRAILER WEIGHT, 200 LB TONGUE WEIGHT. WARNING: CONSULT VEHICLE OWNERS MANUAL FOR TOWING RECOMMENDATIONS AND LIMITATIONS. THIS PRODUCT IS DESIGNED FOR TRAILER TOWING ONLY AND SHOULD NOT BE USED FOR ANY OTHER PURPOSE.

WARNING: USE ONLY RIGID HITCH APPROVED AND MANUFACTURED DRAW BAR INSERT OR WARRANTY WILL BE VOID

NOTE: INSTALL PARTS LOOSELY UNTIL ALL ATTACHMENTS HAVE BEEN MADE TO VEHICLE



- 1. Temporarily lower exhaust by removing 2 studs from rubber isolators.
- 2. Raise hitch into place making note of attachment holes that align with slots in hitch side brackets.
- 3. Lower hitch. Using fish wires provided fish (4) 7/16" carriage bolts and (4) 1×3 block plates into frame rails through large access holes and down through the noted attachment holes.
- 4. Using care not to push the carriage bolts back into the frame, raise the hitch into place and secure with conical washers and hex nuts provided.
- 5. Use a torque wrench to tighten all fastners to the appropriate specifications shown below.
- 6. Raise exhaust back into place and reinstall the 2 studs removed in step 1.

Thank you for purchasing a Rigid Hitch

TIGHTEN ALL FASTENERS TO THE TORQUE SPECIFICATIONS SHOWN BELOW

Hardware Package:

(4) 7/16 - 14 x 1 3/4" Carriage Bolts

(4) 1/4 x 1 x 3" Block Plates (2) 7/16" Fish Wires

(4) 7/16" Conical Washers

(1) UB-6001 Draw Bar Kit

(4) 7/16 Hex Nuts

GIVE THIS INSTRUCTION SHEET TO VEHICLE OWNER

BOLT TIGHTENING TORQUE (LB-FT)			3-FT)
BOLT SIZE	TORQUE	<u>BOLT SIZE</u>	<u>TOŔQUE</u>
3/8" 7/16" 1/2" 3/4"	25 LB FT 50 LB FT 60 LB FT 120 LB FT	8MM 10MM 12MM	20 LB FT 38 LB FT 68 LB FT

THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR SAE AND VESC REGULATION V-5 FOR CONNECTING DEVICES AND TOWING SYSTEMS. DO NOT MODIFY THIS PRODUCT. INSTALL ONLY ON SPECIFIED VEHICLES IN GOOD CONDITION.

